


Installation Manual

SUZUKI SPLASH 5DR
SUZ-SPLA-5-A



COMPONENTS INCLUDED



CL-M02 x 2



CL-M05 x 4



CL-M01 x 2



CL-T01 x 1

Installation

SUZUKI SPLASH 5DR
SUZ-SPLA-5-A



Installation

SUZUKI SPLASH 5DR
SUZ-SPLA-5-A

